

## Safety Precautions

- Do not place the Dome where water can build up.
- Always stand the Dome vertically with the clear plastic dome on top. The Dome is not designed to be used in any other position.
- Make sure the base air vents are not blocked.
- Do not paint or cover the Dome, or in any way block the light path.
- Always connect the Dome to mains power as specified on the serial number label.
- Use only undamaged cables rated for outdoor use.
- Do not disassemble the base. There are no user-serviceable parts inside.

## Specifications

- IP Rating: ..... IP 44
- PAL 1200 Dome Power and Current: ..... 160 W, 0.7 A at 230 V/50 Hz
- MAC 1200 Dome Power and Current: ..... 160 W, 0.7 A at 230 V/50 Hz
- MAC 500/600 Dome Power and Current: ..... 105 W, 0.5 A at 230 V/50 Hz
- AC Voltage and Frequency: ..... 230 V, 50-60 Hz
- Diameter: ..... 880 mm
- PAL 1200 Dome Height, Weight: ..... 1740 mm, 55 kg
- MAC 1200 Dome Height, Weight: ..... 1380 mm, 53 kg
- MAC 500/600 Dome Height, Weight: ..... 1020 mm, 52.5 kg