

DMX PROTOCOL

DMX channel		Value	Function
Mode 1	Mode 2		
1		0 - 74	Strobe, Stand-Alone, Reset No function
		75 - 138	Strobe on (Fast → Slow)
		139 - 170	Remote Stand-alone auto-trigger
		171 - 202	Remote Stand-alone music-trigger
		203 - 255	Reset
	2 - 5 (Head 1 - 4)		0 - 15
		16 - 30	White → Color 1
		31 - 45	Color 1 → Color 2
		46 - 60	Color 2 → Color 3
		61 - 75	Color 3 → Color 4
		76 - 90	Color 4 → Color 5
		91 - 105	Color 5 → Color 6
		106 - 120	Color 6 → Color 7
		121 - 135	Color 7 → Color 8
		136 - 150	Color 8 → Color 9
		151 - 165	Color 9 → Color 10
		166 - 180	Color 10 → Color 11
		181 - 184	Color Wheel "Snaps" (Head 1 - 4) Color 11
		185 - 189	Color 10
		190 - 194	Color 9
		195 - 199	Color 8
		200 - 204	Color 7
		205 - 209	Color 6
		210 - 214	Color 5
		215 - 219	Color 4
		220 - 224	Color 3
		225 - 229	Color 2
		230 - 234	Color 1
		235 - 239	White
	240 - 255	Blackout	
-	6	0	Color Speed Tracking
		1 - 255	Speed (fast → slow)