

Order your Spare Parts online here -> lightspares.com Worldwide Express Delivery
Part or number not found? Send us a request! -> [Contact us!](#)

Spare Parts List of ADB Europe DW 105 ©

30191	
31770	
30079	TCC M4x10 black screw
32268	New cassette
30001	
30084	1 kW cassette
30313	
33865	Fixing screw for door latch
30560	Door latch
32052	Lens tube door
32013	
31893	
30025	
32012	
30404	
30402	
30416	
30417	
30412	Focus knob
30359	
30907	
36305	Zoom 3 PC lens Ø152.4 / RC163 PC152/RC163
33410	Lens fastener
34606	Lens joint
31447	
40606	
30578	
30035	
32119	
40641	
30403	
36304	Zoom 2 PC lens Ø114.3 / RC216 PC114/RC216
32200	
36303	Zoom 1 PC lens Ø114.3 / RC163 PC114/RC163
32201	
40687	
32314	
32480	
32311	
30001	
32312	Rotation control knob
30428	
40687	



Order your Spare Parts online here -> lightspares.com Worldwide Express Delivery
Part or number not found? Send us a request! -> [Contact us!](#)

30101	
1001.31.906	Old cassette replacement kit K/CAS/DS-DW/1
30004	fixed male connector
30011	aluminium reflector
30014	grab handle
30036	2m cable w/ CEE22 socket & no plug CEUROPE
30041	focussing screw rod
30167	lamphouse door
30200	backplate subassembly
30547	reflector mounting clip
30560	door latch
30801	yoke and clamping handle subassembly
32024	reflector holder
32044	GX 9,5 lampholder kit KfF/GX9SCI)FVD1
32046	lampholder support
32047	lamp tray
32050	safety screw
33388	brass wing nut
33865	fixing screw for door latch
34754	clutch release handle
36300	condenser lens Ø 68 LDOC68
36301	intermediate PC lens Ø 89 PC89/RC70.4
36351	Optical subassembly
1001.31.356	CEE 22 socket kit CEE22/PLUG
1000.36.930	Set of 4 beam shaping shutters CM/D1 05-205
1000.40.085	Retention ring for gobo size A RRJGO/A
30380	
33383	
30381	
30906	
30620	
30371	
32059	
32259	
32009	
32007	
32011	
30359	
32950	
30357	
30001	
30087	
40687	
32014	
36301	



Your online store for all stage lighting spare parts <https://lightspares.com>
©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Order your Spare Parts online here -> lightspares.com Worldwide Express Delivery
Part or number not found? Send us a request! -> [Contact us!](#)

40632
40729
30547
32023
30144
32041
32030
32027
32042
40721
32029
40619
32065
30080
32220
32811
33965
33966
30023
30046
30798
30020
32071
33965
32002
30001
30194
30193
30016
30161
30018
30250



Your online store for all stage lighting spare parts <https://lightspares.com>
©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria