

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**

Complete Spare Parts List of ROBE DMX Control 24

13050062	Connector fem. JACK 63 angular f. PCB
13050600	Connector PAW -254-04 PSH02-04P Gold
13050015	Fuse socket PCB
13040515	IC EEPROM 24C64 DMX Control 24/E V 1.0/IC2
13040516	IC EEPROM 24C64 DMX Control 24/E V 1.0/IC3
13040517	IC EEPROM 24C64 DMX Control 24/E V 1.0/IC4
13040518	IC PIC 16C57 DMX Control 24 V1.0/IC1
11010794	Panel - main
13030086	PCB Main EZX1F
13030044	PCB2 Source EZX11
12050077	Plexiglass f. display 19x13
13050064	Plug f. line cord - male GSD781
13050044	Plug male PCB PAW-254-04
17030018	Spacer CS10 plastic
12010001	Spacer D6xL11 M3
13050048	Switch - Key 501
13010018	Transformer BWEI 3052051 230V/9V,3VA
13170299	Wires set f. DMX Control 24 230V Power
13170298	Wires set f. DMX Control 24 without Power-wires
13050053	XLR female 3-pin, PCB, angle, FDPH

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**