

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>  
[www.lightspares.com](http://www.lightspares.com) | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**

**Complete Spare Parts List of  
ROBE FAZE 1050 FT**

13050645	Connector for remote control (5 pin)
13050646	Euro connector
16030016	Fan DP200A 120x120 AC220V
13051578	Heater group Faze 1050FT
13031145	Infrared Ray Liquid Sensor PCB
13031146	PCB - LED Indicator
13030785	PCB DMX 3 pin
13030786	PCB DMX 5 pin
13030904	PCB Main Faze 1050 FT
99013600	Piping assembly (Faze 1050 FT)
13050663	Pump - type EX7 (240V 50Hz)
13051553	Remote control Faze 1050 FT, Fog 1550 FT
13050642	Switch main
17030240	Tank (25 Liter)
13051729	Thermostat 250°C/Faze 1050 FT

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>  
[www.lightspares.com](http://www.lightspares.com) | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**