

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>  
[www.lightspares.com](http://www.lightspares.com) | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**

**Complete Spare Parts List of  
ROBE FOG 1550 FT**

13050677	Breaker ZE-800 (230V/7A)
13050645	Connector for remote control (5 pin)
13051579	Heater group Fog 1550FT
13031145	Infrared Ray Liquid Sensor PCB
13031322	Infrared Ray Liquid Sensor PCB - Fog 1550 FT
13031146	PCB - LED Indicator
13030785	PCB DMX 3 pin
13030786	PCB DMX 5 pin
13030905	PCB Main Fog 1550 FT
99013599	Piping assembly (Fog 1550 FT)
13050663	Pump - type EX7 (240V 50Hz)
13051553	Remote control Faze 1050 FT, Fog 1550 FT
13050642	Switch main
17030249	Tank (6 Liter)
13051756	Thermostat 220Â°C/Fog 1550 FT

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>  
[www.lightspares.com](http://www.lightspares.com) | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**