

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Complete Spare Parts List of COEMAR Infinity ACL M

272.334	lens lockin ring
294.228	lens spacer
LE94	fresnel lens
272.335	lens holder ring
A-2138	cover assembly
A-2136	base cover assembly
A-PLA165	yoke cover
294.110	iris support
FO5054	iris assembly
MMD431	spacer H17
IN82	gear
VE27	fan
294.233	conveyor
294.239	conveyor #1
294.235	conveyor #2
IN115	ingranaggio
MMD384.258	spacer H3
A-GO02	gobo support
A-GO20	gobo wheel
A-GO03	gobo support reset
272.157	sensor support
EL0107441	sensor
294.225	main plate
272.194	connector lock
CN23	24 poles connector
MMD284	spacer H8
MT36	motor 40x40 shaft 28
MMD200	spacer H1
MMD131	spacer H11
IN128	MXL pulley
CD11	1120 MXL belt
272.156	motor holder
MT33	motor 40x40 shaft 9mm
272.239	antireflection
A-VT321	frost assembly
	motor 40x40 shaft
MT33	30mm
MMD220	spacer H8
CU32	bearing
IN95/1	gear
MMD331	flare spacer H1
MMP401	pole H6,5

294.227	adjusting bracket
IN127	gear
294.057	frost assembly holder
MMD233	spacer H37
294.160	heat shield
272.064	lower limiter
272.075	upper limiter
IN127	gear
MMP405	perno H28,5
294.135	main plate
MMD284	spacer H8
CN23	24 poles connector
272.194	connector lock
MT33	motor 40x40 shaft9mm
MT26	motor 40x40 shaft14mm
	motor 40x40 shaft
MT36	28mm
CD28	584 MXL belt
MM6362	spacer
IN28	MXL pulley
IN95/1	gear
CU32	DX bearing
272.133	strobo gear
272.128	strobo DX
272.129	Strobo SX
EL0500288	sensor
CU31	SX bearing
	motor 40x40 shaft
MT48	13mm
272.140	motor cover
MMP399	pole
MMP411	pole H18
A-RUCOL20	color wheel
VT353	blue filter
VT357	red filter
VT351	orange filter
FC050	CTO filter
VT355	UV filter
A-VT319SX	yellow filter left
A-VT319DX	yellow filter right
A-VT318SX	magenta filter left
A-VT318DX	magenta filter right
A-VT136SX	cyan filter left
A-VT316DX	cyan filter right
A-VT287/L	right dimmer
A-VT286/L	left dimmer
272.123	gear
CU31	bearing with flange

IN95/1	gear
CU32	bearing
294.063	lamp assembly holder
VE31	fan 40x40
A-FC051	front head shield
294.055	reflector holder
PAS16/1	reflector
MMD434	spacer H4
272.113	reflector locker
L105830	700 Minifastfit lamp
272.080	lampholder support
PR19	lampholder
MO1093	spring
VE47	fan 60x60
294.248ASM	counterweight
294.222	connector holder
MR316	connector
294.223	insulator plate
294.054	heat shield DX
294.251	conveyor #1
294.065ASM	lamp cover
294.089	conveyor #2
PA478	rear panel
294.052	lamp group chassis
VI458	4x40 screw
GA15/1	locking receptacle
PA493	lamp hatch
GA15/9	plastic washer
GA15/5	locking pin
GA15/3	spring
GA15/4	holding washer
294.084	fan holder
294.224	fan insulator
VE34	turbo fan
PLA171	frontal flange
FUS015	strutter
272.129	counterweight
MMA94	pivot pole
GA15/1	locking receptacle
272.107	rear housing holder
294.083	right group holder
294.060	light shield
294.082	left group holder
272.096ASM	rear header
272.117	front housing holder
MT22	MT22
260.084	motor holder

EL1005408	sensor
8697.86	sensor holder
MV23	shock absorber
IN93	pulley W/ encoder
GA15/1	receptacle
MMD253	spacer 29mm
CD24	MXL belt
IN36/4L	MXL pulley
MMF196	pulley flange
272.062	yoke flange
CU02/1L	bearing
260.160	bearing locking
259.011	locking sensor
MMD387	reset holder
260.162	pole guide
MMD403	spacer 1mm
272.260	hook holder
MMP353	tilt hook pole
260.145	butterfly plate
PA496	front cover
294.076	PCB mobile holder
EL1007456/1	5 motors PCB
MM5259	spacer 10mm
294.075	PCB holder
MM5259/3	spacer 20mm
272.050ASM	assembled yoke
MMD378	teflon washer
272.056	cables cover
287.023	lower sector
MMA79	sector holder
MMP352	hook
8661.69	frict. Grain holder
272.055	yoke holder
PA497	rear cover
AC19	ignitor
MMD11	spacer 6mm
MMD381	teflon spacer
CU24	bearing
MMP321	tightening pin
8661.273	tightening holder
AL51	switching PSU
VE51	60x60 fan
294.050	fan holder
294.051	ballast holder
AL54	ballast 700/575 halogen
294.107	ballast locker
MEI04	main switch

PO1339	fuse holder
PRS04	cable holder
MMG149	handle
294.102	handle holder
GA15/1	receptacle
PA492	warning panel
PA494	fuses panel
MM2395	nut PG 13,5
294.100	handle holder
272.014	PCB holder
MM6362	spacer 5mm
MV88	insulator
MR07	terminal block
EL0906433E	main PCB
294.105	PSU holder
272.012ASM	lower base plate
EL0609491	display
272.016	saftey hook
GA11/2	receptacle
8681.79	receptacle spacer
272.009	reinforcement plate
PA498	lower cover plate
MMD320	spacer
VO04	foot d=25
EL1108477	PCB holder
272.263	ethernet connector
EL0605398	XLR3 DMX connector
EL1204380	XLR5 DMX connector
PA481	DMX panel
MV106	firewall lining
CO9112	camlock plate
RL11	seger
8717.51	spacer
MMD412ASM	bearing holder
CD09	MXL 170 belt
IN36/L	MXL 130 pulley
8697.100	reset ring
8697.101	upper reset ring
8697.102	reset plate
RL10	seger
8720.32	reset ring
MMD187	spacer 5mm ballast ring
8720.64	reinforcement
272.006	rotating shaft support
MMA93	shaft
MT22	motor 55x55

8681.75	motor holder
MM6362	spacer 5mm
EL1005408	sensor
MM51/1L	encoder spacer
IN93	pulley W/ encoder
8681.76	tightening holder
MMP258	tightening pole
CU23	spacer bearing
MMD196	teflon spacer
8697.85	tightening locking
MV76	neoprene washer

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**