

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>  
[www.lightspares.com](http://www.lightspares.com) | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

## Complete Spare Parts List of COEMAR Infinity Wash M

LE1296	fresnel lens
A-2138	cover assembly
A-2136	base cover assembly
A-PLA165	yoke cover
MMD331	flared spacer H1
CU32	bearing
IN95/1	gear
A-LEPC56	3 x zoom lens
MMP401	pole
IN128	MXL 24 pulley
IN109	MXL 40 pulley
CD25	belt
294.227	limiter
IN127	gear
294.229	zoom holder
MMP287	shaft H44
MMF130ASM	bearing W/flange
MT33	motor 40x40 shaft 14 mm
OB26	zoom lens
272.194	connector locker
MMD284	spacer H8
MMP377	pole
MMD40	spacer H1 d=13
CU24	bearing
MT40	motor 40x40 shaft 15 mm
MM6653	spacer H13 d=3
IN24	pinion
CD04	belt
MMP399	pole
272.040	main plate
EL0107441	sensor
272.247	fastener
CU10	guide
CU10/5	carriage
CN23	24 poles connector
8672.45	belt locker
272.037	belt locker holder
MV65	magnet
MMD429	magnet holder
MMD220	spacer H8

MMD200	spacer H1
MMD384.258	spacer H3
8697.72	spacer H0,25
IN117	MXL48 pulley
294.241	spacer
272.047	prism wheel
272.171	spring spacer
272.169	spring
MMP407	gear hub
SPR05	prism support
SPR04	prism support with reset
LEPR32	3 facet prism
LEPR25	ovalizer prism
VT281	striped prism
294.160	heat shield
272.064	lower limiter
272.075	upper limiter
IN127	gear
MMP405	perno H28,5
294.135	main plate
MMD284	spacer H8
CN23	24 poles connector
272.194	connector lock
MT33	motor 40x40 shaft 9mm
MT26	motor 40x40 shaft 14mm
MT36	motor 40x40 shaft 28mm
CD28	584 MXL belt
MM6362	spacer
IN128	MXL pulley
IN95/1	gear
CU32	Dx bearing
272.133	strobo gear
272.128	strobo dx
272.129	strobo sx
EL0500288	sensor
CU31	bearing
MT48	motor 40x40 shaft 13mm
272.140	motor cover
MMP399	pole
MMP411	pole H18
A-RUCOL20	color wheel
VT354	blue filter
VT358	red filter
VT352	orange filter
FC049	CTO filter
VT356	green filter
A-VT332SX	yellow filter left

A-VT332DX	yellow filter right
A-VT331SX	magenta filter left
A-VT331DX	magenta filter right
A-VT330SX	cyan filter left
A-VT330DX	cyan filter right
A-VT287/L	right dimmer
A-VT286/L	left dimmer
272.123	gear
CU31	bearing with flange
IN95/1	gear
CU32	bearing
294.063	lamp assembly holder
VE31	fan 40x40
A-FC051	front heat shield
294.055	reflector holder
PAS16/1	reflector
MMD434	spacer H4
272.113	reflector locker
L105830	700 minifastfit lamp
272.080	lampholder support
PR19	lampholder
MO1093	spring
VE47	fan 60x60
294.248ASM	counterweight
294.222	connector holder
MR316	connector
294.223	insulator plate
294.054	heat shield DX
294.251	conveyor #1
294.065ASM	lamp cover
294.089	conveyor #2
PA478	rear panel
294.052	lamp group chassis
VI58	4x40 screw
GA15/1	locking receptacle
PA493	lamp hatch
GA15/9	plastic washer
GA15/5	locking pin
GA15/3	spring
GA15/4	holding washer
294.084	fan holder
294.224	fan insulator
VE34	turbo fan
272.018	front ring
MMD335	spacer H11
272.025	lens holder
FUS015	strut

MMA94	pivot pole
294.231	right group holder
GA15/1	locking receptacle
272.042	front housing holder
272.107	rear housing holder
272.044	light shield
272.042	zoom holder
272.096ASM	rear header
294.232	left group holder
MT22	motor 55x55
260.084	motor holder
EL1005408	sensor
8697.86	sensor holder
MV23	shock absorber
IN93	pulley with encoder
GA15/1	receptacle
MMD253	spacer 29mm
CD24	MXL belt
IN36/4L	MXL pulley
MMF196	pulley flange
272.062	yoke flange
CU02/1L	bearing
260.160	bearing locking
259.011	locking sector
MMD387	reset holder
260.162	pole guide
MMD403	spacer 1mm
272.260	hook holder
MMP353	tilt hook pole
260.145	butterfly plate
PA496	front cover
294.076	PCB mobile holder
EL1007456/1	5 motor PCB
MM5259	spacer 10mm
294.075	PCB holder
MM5259/3	spacer 20 mm
272.050ASM	assembled yoke
MMD378	teflon washer
272.056	cables cover
287.023	lower sector
MMA79	sector holder
MMP352	hook
8661.69	frict. Grain holder
272.055	yoke holder
PA497	rear cover
AC19	ignitor
MMD11	spacer 6 mm

MMD381	teflon spacer
CU24	bearing
MMP321	tightening pin
8661.273	tightening holder
AL51	switching PSU
VE51	60x60 fan
294.050	fan holder
294.051	ballast holder
AL54	ballast 700/575 halogen
294.107	ballast locker
MEI04	main switch
PO1339	fuse holder
PRS04	cable holder
MMG149	handle
294.102	handle holder
GA15/1	receptacle
PA492	warning panel
PA494	fuses panel
MM2395	nut PG 13,5
294.100	handle holder
272.014	PCB holder
MM6362	spacer mm5
MV88	insulator
MR07	terminal block
EL0906433E	main PCB
294.105	PSU holder
272.012ASM	lower base plate
EL0609491	display
272.016	safety hook
GA11/2	receptacle
8681.79	receptacle spacer
272.009	reinforcement plate
PA498	lower cover plate
MMD320	spacer
VO04	foot d=25
EL1108477	PCB holder
272.263	ethernet connector
EL0605398	XLR 3 DMX connector
EL1204380	XLR 5 DMX connector
PA481	DMX panel
MV106	firewall lining
CO9112	camlock plate
RL11	seger
8717.51	spacer
MMD412ASM	bearing holder
CD09	MXL 170 belt
IN36/3L	MXL 130 pulley

8697.100	reset ring
8697.101	upper reset ring
8697.102	reset plate
RL10	seger
8720.32	reset ring
MMD187	spacer 5 mm
8720.64	ballast ring reinforcement
272.006	rotating shaft supply
MMA93	shaft
MT22	motor 55x55
8681.75	motor holder
MM6362	spacer 5 mm
EL1005408	sensor
MM51/1L	encoder spacer
IN93	pulley with encoder
8681.76	tightening holder
MMP258	tightening pole
CU23	spacer bearing
MMD196	teflon spacer
8697.85	tightening locking
MV76	neoprene washer

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>  
[www.lightspares.com](http://www.lightspares.com) | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**