

Order your Spare Parts online here -> lightspares.com Worldwide Express Delivery
Part or number not found? Send us a request! -> [Contact us!](#)

Spare Parts List of Coemar Reflection LedKo Variwhite©

PLA186/1	SAFETY HOOD
V1539	4X10 SCREW
GA-OTTICALEDKO	OPTIC GROUP
298.041	OPTICS HOLDER
DA220	CAP NUT Ø03
DA231	SELF LOKCK NUT
VI1293	4X14 SCREW
298.004	YOKE PLATE
RVSP3X12	3X12 SCREW
VI530	3X14 SCREW
DA215	NUT Ø06
MA15	KNOB 6X40
PLA177	BODY CASING
298.059	RIGHT SHIELD
VI6644	SCREW 2.9X13
GA-298.012	REAR PANEL HOLER
VI554	SCREW 6X30
MMD446	SPACER H=38
MMD445	SPACER H=30
VI534	LED GROUP
VE56	3X30SCREW
VI579	FAN
RL838	SCREW 8X20 WASHER ØE24 ØI8
MA05	HANDLE
RL412	WASHER
298.003	YOKE
VI591	LOCK BOLT
RL734	CUP WASHER
DA235	SELF LOCK NUT Ø8
DA241	SELF LOCK NUT Ø3
298.060	LEFT SHIELD
298.024ASM	FAN HOLDER
AL42	POWER SUPPLY UNIT
MMD451	PCB FASTENER
MV108	MYLAR INS. SHEET
298.062	PCB HOLDER
MV22	PCB FASTENER
EL0108461L	CONTROL PCB
EL0909462	DISPLAY PCB
MM5259	SPACER H=10
MV6371	DISPLAY SCREEN
RL1297	WASHER Ø03



Your online store for all stage lighting spare parts www.lightspares.com
©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Order your Spare Parts online here -> lightspares.com Worldwide Express Delivery
 Part or number not found? Send us a request! -> [Contact us!](#)

VI528	3X10 SCREW	
298.002	REAR PANEL HOLER	
MEPR07	MAINS PLUG IN	
EL1204380	DMX XLR5 PCB	
MEPR08	MAINS PLUG OUT	
MV88	FERRITE CORE	
VI614	2.9X6.5 SCREW	
PLA175	CAP NUT Ø03	
GR1442	SET SCREW D=4	
VT402/1	LENS	
DA212	NUT D=3	
RD415	STAR WASHER D=5	
A-LE54	LENS ASSEMBLY	
298.040	SPACER	
RL1297	FLAT WASHER D=3 L	
RL409	FLAT WASHER D=3	
GR3X20	D=3 SET SCREW	
298.006	HEAT SINK	
ETC339	STICKER BACK	
ETC351	STICKER RIGHT SIDE	
ETC354	STICKER LEFT SIDE	
ETC319	STICKER YOKE RIGHT SIDE	
ETC353	STICKER RIGHT SIDE	
ETC352	STICKER LEFT SIDE	
ETC340	STICKER YOKE LEFT SIDE	
ETC360	STICKER PROFILE 28/40 LEFT SIDE	PROFILE 28/40
ETC359	STICKER PROFILE 28/40 RIGHT SIDE	PROFILE 28/40
VSP3X10	3X10 SCREW	PROFILE 28/40
298.056	FRONT LENS RING	PROFILE 28/40
LE95	FRONT LENS	PROFILE 28/40
PLA178	LENS HOLDER	PROFILE 28/40
298.055	FRONT LENS RING 2	PROFILE 28/40
VI848	3,5X6,5 SCREW	PROFILE 28/40
MMP450	LENS MOVING POLE	PROFILE 28/40
298.057	REAR LENS RING	PROFILE 28/40
LE96	REAR LENS	PROFILE 28/40
298.058	REAR LENS RING 2	PROFILE 28/40
298.020	GASKET HOLDER	PROFILE 28/40
MMG166	GASKET	PROFILE 28/40
PLA179/1	UPPER CASING	PROFILE 28/40
PLA182	RIGHT SPRING HOLDER	PROFILE 28/40
VI5188	C/TERSUNK 3,5X13 SCREW	PROFILE 28/40
MO26/1	LOCKING SPRING	PROFILE 28/40
MO35	SPRING	PROFILE 28/40
PLA183	LEFT SPRING HOLDER	PROFILE 28/40



Your online store for all stage lighting spare parts www.lightspares.com
 ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Order your Spare Parts online here -> lightspares.com Worldwide Express Delivery
 Part or number not found? Send us a request! -> [Contact us!](#)

VI1062	4X12 SCREW	PROFILE 28/40
MMD381	TEFLON SPACER	PROFILE 28/40
MA14	KNOB	PROFILE 28/40
VI811	3,5X13 SCREW	PROFILE 28/40
298.032	RECEPTACLE COVER	PROFILE 28/40
DA231	SELF LOCK NUT D=4	PROFILE 28/40
VO877	BLADE HANDLE	PROFILE 28/40
VI527	3X8 SCREW	PROFILE 28/40
DA241	SELF LOCK NUT D= 3	PROFILE 28/40
298.030	REAR BLADE PLATE	PROFILE 28/40
298.031	INNER PLATE	PROFILE 28/40
298:038	BAFFLE PLATE	PROFILE 28/40
MO54	SPRING	PROFILE 28/40
PLA184	FRAME HOLDER	PROFILE 28/40
PLA179/1	LOWER CASING	PROFILE 28/40
298.029	BLADE	PROFILE 28/40
LE1296	FRESNEL LENS	FRESNEL
PLA178	LENS HOLDER	FRESNEL
VI848	3,5X6,5 SCREW	FRESNEL
MMP450	LENS MOVING POLE	FRESNEL
298.020	GASKET HOLDER	FRESNEL
MMG166	GASKET	FRESNEL
PLA179/1	UPPER CASING	FRESNEL
PLA182	RIGHT SPRING HOLDER	FRESNEL
VI5188	C/TERSUNK 3,5X13 SCREW	FRESNEL
MO26/1	LOCKING SPRING	FRESNEL
MO35	SPRING	FRESNEL
PLA183	LEFT SPRING HOLDER	FRESNEL
VI1062	4X12 SCREW	FRESNEL
MMD381	TEFLON SPACER	FRESNEL
MA14	KNOB	FRESNEL
VI811	3,5X13 SCREW	FRESNEL
298.032	RECEPTACLE COVER	FRESNEL
DA231	SELF LOCK NUT D=4	FRESNEL
VO877	BLADE HANDLE	FRESNEL
VI527	3X8 SCREW	FRESNEL
DA241	SELF LOCK NUT D=3	FRESNEL
298.030	REAR BLADE PLATE	FRESNEL
298.031	INNER PLATE	FRESNEL
298.038	BAFFLE PLATE	FRESNEL
MO54	SPRING	FRESNEL
298.029	BLADE	FRESNEL
PLA184	FRAME HOLDER	FRESNEL
PLA179/1	LOWER CASING	FRESNEL
ETC355	STICKER FRESNEL LEFT SIDE	FRESNEL



Your online store for all stage lighting spare parts www.lightspares.com
 ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Order your Spare Parts online here -> lightspares.com Worldwide Express Delivery
Part or number not found? Send us a request! -> [Contact us!](#)

ETC356	STICKER FRESNEL RIGHT SIDE	FRESNEL
LE4090	PC ANTIHALO LENS	PC
PLA178	LENS HOLDER	PC
VI848	3,5X6,5 SCREW	PC
MMP450	LENS MOVING POLE	PC
298.020	GASKET HOLDER	PC
MMG166	GASKET	PC
PLA179/1	UPPER CASING	PC
PLA182	RIGHT SPRING HOLDER	PC
VI5188	C/TERSUNK 3,5X13 SCREW	PC
MO26/1	LOCKING SPRING	PC
MO35	SPRING	PC
PLA183	LEFT SPRING HOLDER	PC
VI1062	4X12 SCREW	PC
MMD381	TEFLON SPACER	PC
MA14	KNOB	PC
VI811	3,5X13 SCREW	PC
298.032	RECEPTACLE COVER	PC
DA231	SELF LOCK NUT D=4	PC
VO877	BLADE HANDLE	PC
VI527	3X8 SCREW	PC
DA241	SELF LOCK NUT D=3	PC
298.030	REAR BLADE PLATE	PC
298.031	INNER PLATE	PC
298.038	BAFFLE PLATE	PC
MO54	SPRING	PC
298.029	BLADE	PC
PLA184	FRAME HOLDER	PC
PLA179	LOWER CASING	PC
ETC357	STICKER PC LEFT SIDE	PC
ETC358	STICKER PC RIGHT SIDE	PC

