

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Complete Spare Parts List of Martin M1

11501012	1.5 m power cable, 3-pin IEC
04222002	10K Ohm Lin Fader 45mm
04222003	10K Ohm Lin Fader 60mm
08220102	3.2x7.5 Pop Rivet Alu/steel cl
02204724	Accutouch 2216 controller
05550021	Button for digiswitch , 1 hole
11860326	Cable 12V power M1 ts Controller
11860279	Cable ButtonUBut Prog MaxxyzC
11840150	Cable Centronics M1 ts Controller
11860306	Cable IICBut/5LCD MWing
11860304	Cable IICMW/10LCD MWing
11860303	Cable IICMW/5LCD MWing
11860327	Cable LVDS M1 ts Controller
11860299	Cable Power 12V MWing Bot
11860300	Cable Power 12V-5V MWing Bot
11860262	Cable PowerDMX MaxxyzC
11860278	Cable TBallCtrl Prog MaxxyzC
11840129	Cable USBFrontCereb MaxxyzC
32023001	Closed cell expanded rubber 3.
05324102	Crimp Terminal small , 2.54m
05501001	Digiswitch
05551058	Encoder knob black D=45 H=6 Axis=6 w. fingerhole
05552009	Faderknob ALPS-RS4511119 Maxxy
05552010	Faderknob ALPS-RS6011Y19004 Large
05741416	Fan 12VDC w Feedb 40x40x10
26600070	Fr. Handrest MaxxC
19040160	Friction Hinge Laptop Style Left
19040161	Friction Hinge Laptop Style Right
05020009	Fuse, 2A slow blow
05247222	IEC Module In-Out Switch Fuse
05741417	Intel M Mobile CPU Cooler
02000212	Intel T3100 Dual Core Processor
05555217	Keycap Cherry -
05555210	Keycap Cherry .
05555218	Keycap Cherry /
05555212	Keycap Cherry @
05555216	Keycap Cherry +
05555028	Keycap Cherry <
05555027	Keycap Cherry >
05555200	Keycap Cherry 0

05555201	Keycap Cherry 1
05555301	Keycap Cherry 1 for LED
05555310	Keycap Cherry 10 for LED
05555202	Keycap Cherry 2
05555302	Keycap Cherry 2 for LED
05555303	Keycap Cherry 3 for LED
05555304	Keycap Cherry 4 for LED
05555305	Keycap Cherry 5 for LED
05555306	Keycap Cherry 6 for LED
05555207	Keycap Cherry 7
05555208	Keycap Cherry 8
05555308	Keycap Cherry 8 for LED
05555209	Keycap Cherry 9
05555309	Keycap Cherry 9 for LED
05555221	Keycap Cherry Clear (Large)
05555222	Keycap Cherry Copy (Large)
05555229	Keycap Cherry Cue (Large)
05555224	Keycap Cherry Delete (Large)
05555219	Keycap Cherry Edit (Large)
05555211	Keycap Cherry Enter (Large)
05555213	Keycap Cherry Full
05555228	Keycap Cherry Group (Large)
05555227	Keycap Cherry Load (Large)
05555223	Keycap Cherry Move (Large)
05555000	Keycap Cherry No text
05555225	Keycap Cherry Record (Large)
05555214	Keycap Cherry Thru
05555220	Keycap Cherry Undo (Large)
05555226	Keycap Cherry Update (Large)
05555026	Keycap Cherry v
05555025	Keycap Cherry ^
05555203	Keycap Cherry 3
05555204	Keycap Cherry 4
05555205	Keycap Cherry 5
05555206	Keycap Cherry 6
05555307	Keycap Cherry 7 for LED
05555215	Keycap Cherry Arrow
05555018	Keycap Cherry Bank
05555030	Keycap Cherry CV
05555016	Keycap Cherry Delay
05555001	Keycap Cherry F1
05555010	Keycap Cherry F10
05555011	Keycap Cherry F11
05555012	Keycap Cherry F12
05555002	Keycap Cherry F2
05555003	Keycap Cherry F3
05555004	Keycap Cherry F4

05555005	Keycap Cherry F5
05555006	Keycap Cherry F6
05555007	Keycap Cherry F7
05555008	Keycap Cherry F8
05555009	Keycap Cherry F9
05555013	Keycap Cherry Fade
05555035	Keycap Cherry Go (Large)
05555023	Keycap Cherry High Light
05555019	Keycap Cherry Last
05555034	Keycap Cherry ll/Back (Large)
05555017	Keycap Cherry Macro
05555014	Keycap Cherry Menu
05555029	Keycap Cherry Mode
05555020	Keycap Cherry Next
05555024	Keycap Cherry P/T
05555021	Keycap Cherry Preview
05555033	Keycap Cherry Rel
05555031	Keycap Cherry Select
05555032	Keycap Cherry Snap
05555015	Keycap Cherry Snap Shot
05555022	Keycap Cherry Swap Prog
11860368	LED Backlight cable f. TFT screen
62440160	LED TFT replacement kit M1 Controller
39041011	LV-679 Core 2 Duo Mini-ITX Mainb
26621080	M. TballBut Left MaxxC
26621090	M. TballBut Right MaxxC
33001116	M1 logoplate
26621370	M1 ts Controller Harddisk Bracket
62409140	M1 ts Controller HingeBracket Back Ass1
26621350	M1 ts Controller HingeBracket Front
26621390	M1 ts Controller Screen Bracket Left
26621380	M1 ts Controller Screen Bracket Right
23402920	M1 ts Controller Screen Hingecover
62409150	M1 ts Controller ScreenHouse Back Ass1
08010402	M2x3 ph pz shiny
08052701	M3 nut lock PA shiny
08054303	M3 washer 3,2/7x0,5 PA
08054301	M3 washer 3,2/7x0,5 shiny
08054401	M3 washer lock 3,2/6 black
08050805	M3x10 cs torx tapt black
08050709	M3x10 ph torx black
08050802	M3x6 cs torx black
08050702	M3x6 ph torx black
08053805	M3x6 stand off f/f PA
08053799	M3x6 stand off m3,7/f3,5 shiny
08050809	M3x8 cs torx tapt spike black
08050703	M3x8 ph torx black

08072701 M4 nut lock PA shiny
08071223 M4x12 ch low allen A2 DIN7964
08070805 M4x8 cs torx tapt spike black
08111211 M6x30 ch low allen black
11501502 Mains cable 3x18AWG IEC-US, 3M Rev A and B
62010549 PCBA 5 LCD wing TEST
62013002 PCBA dc filter (Case lamp)
62011518 PCBA DC/DC MaxMod TEST
62010558 PCBA M1 ts Controller Playback TEST
62010559 PCBA M1 ts Controller Program TEST
62010557 PCBA M1 ts Controller Submasters TEST
62010561 PCBA M1 ts Controller WheelEnc TEST
62014508 PCBA M1 ts FuseBoard
62011039 PCBA M1 ts Led Inverter Test
62010546 PCBA Tball Controller TEST
62010542 PCBA Tball UpperButt. TEST
62011035 PCBA USB/DMX 2048 MM TEST
62014504 PCBA USBFront Cerebrum TEST
34240015 Plastic bag 500x600x0,02mm
34240018 Plasticbag 250x360x40x0,04mm
06150021 PSU UNI 90-240VAC 12VDC 160W
08200102 PT 2,9x6,5 ph torx black
05501016 Push Switch w LCD 3Col 64x32Pi (type: SB6432)
19440140 Rubber foot FF-7
23401335 Rubseal base handle MAC550 DK
62409170 ScreenHouse Front Ass1 M1 ts Controller
39046011 SODIM DDRII Ram 2GB Dual Ch Kit2
39041507 SSD Drive 2.5 SATA
13104003 Strap, black, 3.6x140mm
13104000 Strap,black,high temp,2.5x98
34206001 Styropor Corner, Large
39100509 TrackBal 38mm blue
13101008 Wire Retainer Flexible
11850132 Wireset High Volt MCerebr Bot

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**