

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Complete Spare Parts List of Martin M2 GO

11501012	1.5 m power cable, 3-pin IEC
04222003	10K Ohm Lin Fader 60mm
08220701	6.3x0.8 Cable Spade Pop Rivet
39041012	Advantech MIO-5270D-S6A1E Kit
05501001	Digiswitch
05551058	Encoder knob black D=45 H=6 Axis=6 w. fingerhole
05552010	Faderknob ALPS-RS6011Y19004 Large
11860378	Internal USB-Mainboard M2Go
05120701	Jumper 2 Pole 2,54mm Spacing
05555217	Keycap Cherry -
05555210	Keycap Cherry .
05555218	Keycap Cherry /
05555212	Keycap Cherry @
05555216	Keycap Cherry +
05555028	Keycap Cherry <
05555027	Keycap Cherry >
05555200	Keycap Cherry 0
05555201	Keycap Cherry 1
05555301	Keycap Cherry 1 for LED
05555310	Keycap Cherry 10 for LED
05555202	Keycap Cherry 2
05555302	Keycap Cherry 2 for LED
05555303	Keycap Cherry 3 for LED
05555304	Keycap Cherry 4 for LED
05555305	Keycap Cherry 5 for LED
05555306	Keycap Cherry 6 for LED
05555207	Keycap Cherry 7
05555208	Keycap Cherry 8
05555308	Keycap Cherry 8 for LED
05555209	Keycap Cherry 9
05555309	Keycap Cherry 9 for LED
05555221	Keycap Cherry Clear (Large)
05555222	Keycap Cherry Copy (Large)
05555229	Keycap Cherry Cue (Large)
05555224	Keycap Cherry Delete (Large)
05555219	Keycap Cherry Edit (Large)
05555211	Keycap Cherry Enter (Large)
05555213	Keycap Cherry Full
05555228	Keycap Cherry Group (Large)
05555227	Keycap Cherry Load (Large)

05555223	Keycap Cherry Move (Large)
05555000	Keycap Cherry No text
05555225	Keycap Cherry Record (Large)
05555214	Keycap Cherry Thru
05555220	Keycap Cherry Undo (Large)
05555226	Keycap Cherry Update (Large)
05555203	Keycap Cherry 3
05555204	Keycap Cherry 4
05555205	Keycap Cherry 5
05555206	Keycap Cherry 6
05555307	Keycap Cherry 7 for LED
05555215	Keycap Cherry Arrow
05555018	Keycap Cherry Bank
05555016	Keycap Cherry Delay
05555001	Keycap Cherry F1
05555002	Keycap Cherry F2
05555003	Keycap Cherry F3
05555004	Keycap Cherry F4
05555005	Keycap Cherry F5
05555006	Keycap Cherry F6
05555007	Keycap Cherry F7
05555008	Keycap Cherry F8
05555013	Keycap Cherry Fade
05555035	Keycap Cherry Go (Large)
05555023	Keycap Cherry High Light
05555019	Keycap Cherry Last
05555037	Keycap Cherry Link
05555034	Keycap Cherry II/Back (Large)
05555017	Keycap Cherry Macro
05555014	Keycap Cherry Menu
05555020	Keycap Cherry Next
05555021	Keycap Cherry Preview
05555033	Keycap Cherry Rel
05555031	Keycap Cherry Select
05555032	Keycap Cherry Snap
05555015	Keycap Cherry Snap Shot
05555022	Keycap Cherry Swap Prog
91613090	LED Desklamp Angular XLR 13
23007470	Lid M2GO/M2PC
08052701	M3 nut lock PA shiny
08050709	M3x10 ph torx black
08050714	M3x16 ph torx black
08050702	M3x6 ph torx black
08050803	M3x8 cs torx black
08050703	M3x8 ph torx black
08110703	M6x12 bh torx black
11501502	Mains cable 3x18AWG IEC-US, 3M Rev A and B

62050021	PCBA M2GO/M2PC Front
34240006	Plastic bag, 600x850
34240018	Plasticbag 250x360x40x0,04mm
08200102	PT 2,9x6,5 ph torx black
32020504	Rubber foot
13104000	Strap,black,high temp,2.5x98
02204506	TFT 3.5 320x240 8-16 bit parallel with Touch
13101008	Wire Retainer Flexible
11040533	Wire yellow/green 1x0,75# 25cm

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**