

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Complete Spare Parts List of Martin Maxxyz Compact

11501012 1.5 m power cable, 3-pin IEC
08240114 1/4 turn fastener, retainer
08240113 1/4 turn fastener, wingbolt
08240115 1/4-turn pedestal
08190101 2.9x4.5 C. rec. Ph. Selftap bl
08220102 3.2x7.5 Pop Rivet Alu/steel cl
91613024 3P fem.XLR - 5P maleXLR adaptr NA3F5M
08190404 4.2x13 Torx20 FH Selftap black
08220602 5.0x10 Pop Rivet grooved alu
08220604 5.0x18 Pop Rivet grooved alu
02204724 Accutouch 2216 controller
26820270 Aluplate Maxxyz wheelplate
55732060 Bluelight unit, MAXxyz
05550021 Button for digiswitch , 1 hole
11860274 Cable ButtonTFTCereb MaxxyzC
11860279 Cable ButtonUBut Prog MaxxyzC
11840127 Cable Cereb-Centronics MaxxyzC
11840122 Cable eUSBMod3 MaxxyzC
11840120 Cable Frame-Centronics MaxxyzC
11860270 Cable IICMasterFader MaxxyzC
11860322 Cable LVDS AUO G121SN01 V3
11860271 Cable PowerCerebIntern MaxxyzC
11860262 Cable PowerDMX MaxxyzC
11860263 Cable PowerMod2 MaxxyzC
11860278 Cable TBallCtrl Prog MaxxyzC
11840129 Cable USBFrontCereb MaxxyzC
34000000 Cardboard box, 504x254x104
32023001 Closed cell expanded rubber 3.
05324102 Crimp Terminal small , 2.54m
05501001 Digiswitch
02205502 Digital encoder belt Blue LED
39042504 DVD RW Slimline drive,MaxxyzC
05741613 Fan 12VDC 60x60x15 Low Noice
05741416 Fan 12VDC w Feedb 40x40x10
33001018 Flightcase writing pad
62406415 FR Keyboard drawer W handrest
26621220 Fr. DVD Brack Left MaxxC
26621230 Fr. DVD Brack Right MaxxC
26600070 Fr. Handrest MaxxC
23402260 Fr. Storage Compart MaxxC

62406450 Fr. TopLight Assembly MaxxC
62406490 Fr. USBDMX MountPlate MaxxC
32023503 Handrest bottom foam
19040110 Hinge part, MAXxyz
26620630 Holder for monitor, MAXxyz
11840126 IDECable DVDIDE 320mm MaxxyzC
02000210 Intel Pentium-M Dothan 1,8GHz
05555217 Keycap Cherry -
05555210 Keycap Cherry .
05555218 Keycap Cherry /
05555212 Keycap Cherry @
05555216 Keycap Cherry +
05555028 Keycap Cherry <
05555027 Keycap Cherry >
05555200 Keycap Cherry 0
05555201 Keycap Cherry 1
05555301 Keycap Cherry 1 for LED
05555310 Keycap Cherry 10 for LED
05555202 Keycap Cherry 2
05555302 Keycap Cherry 2 for LED
05555303 Keycap Cherry 3 for LED
05555304 Keycap Cherry 4 for LED
05555305 Keycap Cherry 5 for LED
05555306 Keycap Cherry 6 for LED
05555207 Keycap Cherry 7
05555208 Keycap Cherry 8
05555308 Keycap Cherry 8 for LED
05555209 Keycap Cherry 9
05555309 Keycap Cherry 9 for LED
05555221 Keycap Cherry Clear (Large)
05555222 Keycap Cherry Copy (Large)
05555229 Keycap Cherry Cue (Large)
05555224 Keycap Cherry Delete (Large)
05555219 Keycap Cherry Edit (Large)
05555211 Keycap Cherry Enter (Large)
05555213 Keycap Cherry Full
05555228 Keycap Cherry Group (Large)
05555227 Keycap Cherry Load (Large)
05555223 Keycap Cherry Move (Large)
05555000 Keycap Cherry No text
05555036 Keycap Cherry No text (Large)
05555225 Keycap Cherry Record (Large)
05555214 Keycap Cherry Thru
05555220 Keycap Cherry Undo (Large)
05555226 Keycap Cherry Update (Large)
05555026 Keycap Cherry v
05555025 Keycap Cherry ^

05555203 Keycap Cherry 3
05555204 Keycap Cherry 4
05555205 Keycap Cherry 5
05555206 Keycap Cherry 6
05555307 Keycap Cherry 7 for LED
05555215 Keycap Cherry Arrow
05555018 Keycap Cherry Bank
05555030 Keycap Cherry CV
05555016 Keycap Cherry Delay
05555013 Keycap Cherry Fade
05555035 Keycap Cherry Go (Large)
05555023 Keycap Cherry High Light
05555019 Keycap Cherry Last
05555034 Keycap Cherry II/Back (Large)
05555017 Keycap Cherry Macro
05555014 Keycap Cherry Menu
05555029 Keycap Cherry Mode
05555020 Keycap Cherry Next
05555024 Keycap Cherry P/T
05555021 Keycap Cherry Preview
05555033 Keycap Cherry Rel
05555032 Keycap Cherry Snap
05555015 Keycap Cherry Snap Shot
05555022 Keycap Cherry Swap Prog
05555230 Keycap Cherry View
05552008 Knop fader f. MAXxyz
08240609 Large Butterfly, Cranked kick
39041009 LV-673ENS PentM Commel Mainb Maxxc
26621080 M. TballBut Left MaxxC
26621090 M. TballBut Right MaxxC
08030502 M2,5x5 cs pz tapt shiny
08052701 M3 nut lock PA shiny
08054303 M3 washer 3,2/7x0,5 PA
08054401 M3 washer lock 3,2/6 black
08050810 M3x10 cs torx black
08050709 M3x10 ph torx black
08053807 M3x10 stand off m6/f7 black
08050706 M3x12 ph torx black
08050812 M3x16 cs torx black
08050714 M3x16 ph torx black
08053814 M3x20 stand off m6/f7 black
08050802 M3x6 cs torx black
08050702 M3x6 ph torx black
08050700 M3x6 ph torx tapt spike black
08053805 M3x6 stand off f/f PA
08053799 M3x6 stand off m3,7/f3,5 shiny
08050804 M3x8 cs torx tapt black

08050703 M3x8 ph torx black
08073001 M4 nut square 8x8x2,7 shiny
08073601 M4 riv nut cs spline 1-3 shiny
08071208 M4x10 ch low allen A4 ds silver
08070804 M4x10 cs torx tapt black
08070701 M4x10 ph torx tapt spike black
08071223 M4x12 ch low allen A2 DIN7964
08070801 M4x8 cs torx black
08091302 M5x16 cs allen shiny
08112701 M6 nut lock PA shiny
08113605 M6 Nutrivet Quicksert, Steel
08111201 M6x10 ch low allen black
08111215 M6x16 Allen Flange Socket
08111204 M6x16 ch allen A2
08111303 M6x16 cs allen A2 ds silver
08112304 M6x20/15 Handwheel Black D40
08111005 M6x30 Hex cap screw black
62010534 PCBA 32Key Programmer TEST
62010535 PCBA 5Digitast TEST
62010547 PCBA 5Digitast WO Cherry TEST
62010536 PCBA 5LCDkey TEST
62010548 PCBA 5LCDkey WO Scrollwh TEST
62010537 PCBA 5Playb Buttons TEST
62010023 PCBA Analog Fader M Slave
62010024 PCBA Analog Fader no Motor
62011020 PCBA AUDIO/Power TEST
62010538 PCBA ChannelSelect TEST
62013002 PCBA dc filter (Case lamp)
62011024 PCBA Digital FaderDriv. TEST
62010539 PCBA Fade-Bank Keys TEST
62010540 PCBA Go Buttons TEST
62010053 PCBA Logo SideLeds TEST
62010052 PCBA Master MotFader TEST
62010541 PCBA MasterFader Ctrl TEST
62011030 PCBA Mini USB/I2C 5FadBot TEST
62011029 PCBA Mini USB/I2C 5FadTop TEST
62010546 PCBA Tball Controller TEST
62010542 PCBA Tball UpperButt. TEST
62011023 PCBA TFT Button CTRL TEST
62010543 PCBA TFT Buttons TEST
62011019 PCBA USB/DMX 2048 TEST
62011021 PCBA USB/HUB 7Port TEST
62011022 PCBA USB/IDE TEST
62010545 PCBA USB/Programmer TEST
62014504 PCBA USBFront Cerebrum TEST
62011025 PCBA VGA/USB Cerebrum TEST
05323522 Plug female angle, wire, 2 pol

39047004 PSU Seasonic V8 300W Maxxc
08200102 PT 2,9x6,5 ph torx black
08200107 PT 5x12 ph pz black
05501016 Push Switch w LCD 3Col 64x32Pi (type: SB6432)
32020501 Rubber foot 38x10mm, Black
15800000 Sleeve flexible ,hose 5mm, bl
39041507 SSD Drive 2.5 SATA
26620650 Stabilizer for monitor holder
13104003 Strap, black, 3.6x140mm
13104000 Strap,black,high temp,2.5x98
16840060 Teleskope med nitte, MAXxyz
02204504 TFT 12.1 AUO G0121SN01 MaxxC
02204703 TFT Invertor f. 12.1 MaxxC
02204721 Touchpanel ELO 12.1 MaxxC
39100508 TrackBal 38mm blue backl MaxxC
08073801 UNC 4-40 stand off m7/f3 shiny
19400060 Wheel, 100 mm, Blue
26860710 Wheelplate MAXxyz Flc.
13101008 Wire Retainer Flexible

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**