

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Complete Spare Parts List of ARRI EB 12000

L4.82533.E	Diode module byt 261 PIV 800	Diodenmodul Byt 261 PIV 800
L4.82513.E	Mains switch	Netzschalter
L4.82532.E	Power FET module	Power FET Modul
L4.82516.E	Dimm pot with knob	Dimmpotentiometer mit Drehknopf
L4.82514.E	Earth test switch	Erdtaster
L4.82567.E	HF-base drive board	HF-Ansteuerung
L4.82550.E	HF-snubber board	HF-Entlastung
L4.82566.E	LF-base drive board	NF-Ansteuerung
L4.82565.E	Control board	Regelkarte
L4.82559.E	HF-capacitor board	HF-Kondensator-Platine
L4.82572.E	HF-Gate-drive board	HF-Gate-Ansteuerung
L4.82568.E	HF-snubber board	HF-Entlastung
L4.82571.E	Control board act. line filter	Regelkarte akt. Netzfilter
L4.82570.E	RF-line filtering board	RF-Netzfilter
L4.82569.E	LF-snubber board	NF-Entlastung
L4.82573.E	Transistor module	Transistormodul
L4.82574.E	Power FET module	Power FET Modul
L4.82576.E	Mains contactor	Schütz
L4.82578.E	Ignitor and start resistor-set (5 pieces)	Zünd- und Startwiderstand-Set (5 Stück)
L4.82575.E	Input rectifier	Netzgleichrichter
L4.82577.E	Input capacitor	Ladeelko
L4.75786.E	Veam output connector (female)	Veam Output Stecker (Buchsenkontakt)

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**