

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Complete Spare Parts List of ARRI EB 575

| | | |
|------------|----------------------------------|---------------------------------|
| L4.82506.E | HF-gate drive cpl. | HF-Ansteuerung kpl. |
| L4.82515.E | Low noise switch with knob | Noise-Schalter mit Drehknopf |
| L4.82513.E | Mains switch | Netzschalter |
| L4.82507.E | Mains board | Trafokarte |
| L4.82508.E | Power FET IRFP 450 FI | Power FET IRFP 450 FI |
| L4.82518.E | Fuse-set (10 pieces) | Feinsicherung-Set (10 Stück) |
| L4.82503.E | Rubber foot-set back (4 pieces) | Gummifuß-Set Rückwand (4 St.) |
| L4.82502.E | Rubber foot-set cpl. (4 pieces) | Gummifuß-Set kompl. (4 Stück) |
| L4.82505.E | LF-gate drive cpl. | NF-Ansteuerung kpl. |
| L4.82504.E | Control board | Regelkarte |
| L4.82501.E | Front handle-set cpl. (2 pieces) | Frontgriffset kompl. (2 Stück) |
| L4.82509.E | Diode bit 30 PI 800 | Diode Bit 30 PI 800 |
| L4.82510.E | Input rectifier | Netzgleichrichter |
| L4.82516.E | Dimm pot with knob | Dimmpotentiometer mit Drehknopf |
| L4.82517.E | Start resistor-set (5 pieces) | Startwiderstand-Set (5 Stück) |
| L4.82514.E | Earth test switch | Erdtaster |

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria