

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>  
[www.lightspares.com](http://www.lightspares.com) | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

## Complete Spare Parts List of Martin Xciter

02005112	XC161 CMOS 16 bit uP, 40MHz
02031512	512K x 8 SRAM, 5V, SOJ-36
02032507	Dual port, RAM 4kB
02034509	256K, I2C, CMOS, serial EPROM
02035526	AM29F016D-70EC 2Mx8 flash
02050106	74 HCT 132 Quad Nand Schmitt trig, SMD
02050108	74 HCT 138 3 TO 8 DECODER ,SMD
02050111	74 HCT 238 3 to 8 decoder ,SMD
02050113	74 HCT 245 Octal Bus tranceiver,SMD
02050114	74 HCT 373 OCTAL LATCH ,SMD
02050120	74 HCT 4051P 8-1 MUX ,SMD
02100201	LM 324 D Quad opamp, SMD
02105225	LD1117, 2.5V, 800mA volt reg, SMD
02105233	LD1117, 3.3V, 800mA volt reg, SMD
02105607	SMPS regulator, 13W
02106101	Programmable Voltage Reference, TL431ACD
02120501	Digital potentiometer, 256 position
02121805	75C176 BiCMOS RS485 Transceiver SMD
02121821	ADM 202EARN ,RS232 Serial Transceiver,SMD
02122004	SN75240, dual USB transient
02122006	CY7C64613-128, EZ-USB, FX ctrl.
02200000	4N25A Opto photo transistor
02200502	TLP113 Opto photo transistor High speed;SMD
02204201	TFDU 4100 IR interface
02205008	Display, LCD 2x40Char, blue, CONN
02205009	Display, LCD 4x20, blue
02300401	BC 847B , SMD
02320602	IRLML2803 Nchan MOSFET 30V 1A
02321206	IRLML5103 P-CH MOSFET 0.6A, -30V, Rdson=0.6 Ohm. SOT-23
02321400	Mosfet, P-channel, 8A, 30V
04010438	15nF, 400V, film
04020327	2n2 Y1 250ac
04020328	2.2 nF 250V Y2 film capacitor
04020352	220nF, X2, 250V film capacitor
04040248	1000uF, 25V, electrolytic, radial
04040340	220uF, 35V, electrolytic, radial
04041206	47uF 400V ELLYT, snap in
04050136	1nF, 50V, ceramic, SMD
04050144	4.7nF, 50V, ceramic, SMD
04050152	22nF, 50V, ceramic, SMD

04050160	100nF, 50V, ceramic, SMD
04050168	470nF, 50V, ceramic, SMD
04050216	22pF, 63V, ceramic, SMD
04050217	27pF, 63V, ceramic, SMD
04050220	47pF, 63V, ceramic, SMD
04050232	470pF, 50V, ceramic, SMD
04081928	22uF, 10V, tantalium, SMD
04082112	1uF, 16V, tantalium, SMD
04082124	10uF, 16V, tantalium, SMD
04150308	120 Ohm Resistor
04170216	15 Ohm, resistor, SMD
04170256	47 Ohm, resistor, SMD
04170300	100 Ohm resistor, SMD
04176000	0R OHM, 5% 0.06W, SMD 0603
04176100	10R Ohm resitor, 1% 0.1W, SMD
04176172	56R Ohm resistor, 1%, 1/10W, SMD 0603
04176200	100R, 1% 0.06W, SMD 0603
04176216	150R OHM RESISTOR, 1% 1/10W, SMD 0603
04176224	180R Ohm resitor, 1%, 1/10W, SMD
04176332	220R OHM, 5% 0.06W, SMD 0603
04176340	560R OHM, resistor, 1% 1/10W, SMD 0603
04176364	470R OHM RESISTOR, 1% 1/10W, SMD 0603
04176372	560R OHM RESISTOR, 1% 1/10W, SMD 0603
04176400	1K Ohm resistor, 1% 0.1W, SMD 0603
04176416	1K5 OHM RESISTOR, 1% 1/10W, SMD 0603
04176432	2K2 Ohm resistor, 1% 0.1W, SMD 0603
04176448	3K3 OHM, 5% 0.06W, SMD 0603
04176464	4K7 Ohm resitor, 1% 0.W, SMD 0603
04176480	6K8 Ohm resitor, 1% 0.1W, SMD 0603
04176500	10K OHM RESISTOR, 1% 1/10W, SMD 0603
04176516	15K Ohm resitor, 1% 0.1W, SMD 0603
04176524	18K Ohm resistor, 1%, 1/10W, SMD
04176532	22K OHM RESISTOR, 1% 1/10W, SMD 0603
04176548	33K Ohm resitor, 1% 0.1W, SMD 0603
04176564	47K OHM RESISTOR, 1% 1/10W, SMD 0603
04176566	56k 1% 0603 100ppm 1/10W
04176592	82 K OHM RESISTOR, 1% 1/10W, SMD 0603
04176600	100K Ohm resitor, 1% 0.1W, SMD 0603
04176632	220K Ohm resistor, 1%, 1/10W, SMD
04176700	1M Ohm, 1% 0.1W, SMD 0603
04200201	100 ohm resistor, 1W, SMD
04222001	10K Ohm Lin Fader 60mm
04222005	10K Ohm, click lin fader, 60mm
04225001	10K Ohm Lin Joystick w lever reset 20.7 x 22.7 x 12.9mm w switch
04251000	NTC 10R / 3A inrush current limitingSMPS applications.
04301001	BAS32L-115 (1N4148) , SMD
04301007	Diode MURS160T3, SMD, ultra fast

04301013	Diode Schottky 15MQ040N SMA 40V, 2.1A Vf=0.42
04303001	Diode bridge, DF04S
04304050	Diode, ZENER BZG03-C200, 200V, 3W
04307002	6V8, diode transil
04307004	Diode transil, 10V
04311001	LED 3mm Green
04350202	X-tal, 32.768kHz, watch
04350213	X-tal 12MHz low profile, SMD Tape
04350215	X-tal 16MHz low profile, SMD Tape
04400008	22uH, OWICH110-220
04400452	Choke-CMD 1.1mH 1.8A
04400605	EMI Chip, 30 Ohm, 3000mA ,0805
04502004	SMPS trafo, SP-E20/6
05020004	Fuse 0.315 AT
05030001	Fuse holder PCB, plastic support
05123001	XLR female 3-pin chassis, PCB, angle, gold
05123102	XLR 5pin female chassis. PCB, angle
05123402	Jack socket mono PCB
05123409	Socket, DIN, 5 pole, PCB
05123429	USB connector, A type, vertical, PCB
05123430	USB connector, B type, vertical, PCB
05124216	Female header SIL-16Pin SMD
Bottom E	ntry Tape/Reel 500pcs
05143102	XLR 5-pin male chassis, PCB, angle
05144007	Header, 8 pole, 2.54mm, PCB
05144060	Header, 40 pole, PCB sil
05144436	Header, 6 pole ang., PCB, schrouded
05144442	Plug 20 pole PCB dual in line schrouded
05144444	Plug 40 pole PCB dual in line schrouded
05144505	Header 6 pole angle, PCB, schrouded
05144541	Head, 20 pole ang PCB schrouded
05144543	Header, 40 pole ang, PCB, schrouded
05147001	Mains socket, PCB ,male I.E.C.
05343201	XLR male 3-pin cable type, black, metal
05500100	DIP switch, 6 pole, SMD
05501030	Tact switch w. red LED
05505010	Rotary encoder, 24 pulse
05550093	8xpushbutton, #2, d=16.5mm, Xciter
05550094	8xpushbutton, #2, d=13.5mm, Xciter
05550095	8xpushbutton, #3, d=13.5mm, Xciter
05550096	8xpushbutton, #4, d=13.5mm, Xciter
05550097	8xpushbutton, #5, d=13.5mm, Xciter
05550098	8xpushbutton, #1, d=13.5mm, Xciter
05550099	8xpushbutton, #1, d=16.5mm, Xciter
05550100	Lightguide, d=16.5mm, Xciter
05550101	Lightguide, d=13.5mm, Xciter
05551048	Scroll button (black), Xciter

05552006	Knob f. fader (black), Xciter
05553002	Knop f. joystick, black, Xciter
05830001	Electret condensor Microphone
06220003	
08050501	M3x4 screw, Phillips, cs, black
08050701	M3x8 taptite, Torx, ph, black
08052701	M3 hex lock nut
08053802	M3x5 stand off, m/f
08053806	M3x7 stand off, m/f, black
08054401	M3 lock washer, black
08070805	M4x8 taptite, Torx, cs, black, spec.
08073601	M4 blind rivet nut, cs
08200101	2.2x4.5 Plastite, ph, black
08200105	3.5x8 eco-syn, ph, black
08200107	5x12 Plastite, ph, black
08220114	3.2x7.44 mm auto rivet
11100502	Wire, yellow/green, awg 18 (1x0.75#), 8cm
11501012	Mains cable I.E.C. 3pin, 1.5 m, Black
11750006	Wireset, 6 pol, flat, Xciter
11760009	Wireset, 20 pol, flat, 27cm
11780003	Wireset, 40 pol, flat, 27cm
11820008	XLR cable 5m black 3P male-3P female
11840066	USB cable (A/B), 1000mm
18620040	Window f. display, 25x155, Xciter
23401450	Top shell, black paint, Xciter
23809570	Front plate, Xciter
23809580	Plate, chassis, Xciter
23809590	Plate, left side, Xciter
23809600	Plate, right side, Xciter
23809610	Side plate, left, Xciter
23809620	Side plate, right, Xciter
26641720	Chassis w. silkprint, Xciter
32020500	Rubber foot 3.6x12.7mm Black
32023510	Handrest, neoprene, Xciter
32023514	Neoprene pad, faders, Xciter
32023515	Rubber ring, joystick, Xciter
32023516	Silicone pad, DJ board, Xciter
33001046	Logo label, Xciter
33160022	Label, connections, Xciter
34000103	Cardboard box, Xciter
34151140	Foam 1, LD18, Xciter
34151150	Foam 2, LD18, Xciter
34151160	Foam 3, LD18, Xciter
34240006	PLAST BAG,600x850mm,Spandepose
35000119	User manual, Xciter
35030119	User manual, French, Xciter
35040119	User manual, Spanish, Club control.

35060119	User manual, German, Xciter
37000203	Loctite 406, 20 g
37000801	Silicon glue clear, low temp. (220-250 °C)
41201008	Lens, PI/Cx, D=88.8
55736001	Front plate w. pads, Xciter
55736002	Front shell module, Xciter
62010029	Main PCB, Xciter Ctrl., tested
62010526	PCB, front, Xciter Ctrl, tested
91613017	Termination Plug XLR , male , 120 Ohm

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>  
[www.lightspares.com](http://www.lightspares.com) | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**