

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**

Complete Spare Parts List of MA Lightcommander 24-6

129945	PSU for LC II
129908	PC board for LC 24/48 preset 1-24 without analogue output
129604	PC board for LC 24/48 preset 1-24 with analogue output
129906	PC board for LC II 24/48 master blue display
129979	PC board for LC II 24/48 master green display
129909	PC board LC II CPU
129772	frontplate master for LC II printed, incl. Plastic pane
129773	frontplate preset and aux for LC II 24/6
129791	frontplate preset 1-24 for LCII 48/6
129927	update LC II 24/6 V2.59
129920	keyswitch for LC II
129915	Keys for keyswitch (2 pieces)
129942	fader radiohm for LC II
129913	knob for fader radiohm for LC II
129950	knob for soundpoti
129917	poti 10KA aux LCII 24/28
129950	knob for poti
129900	battery for LC
129912	knob for fader alpha green/red 4x1 mm plastic
129911	knob for fader alpha green/white 4x1mm plastic
129976	knob for fader alpha green/red 4x1 mm rubberized
129975	knob for fader alpha green/white 4x1mm rubberized
129902	button 17mm grey
129956	button 17mm grey with led
129903	button 17mm grey with 2 led
129960	button 12mm grey
129961	button 12mm 1led
129963	button 12mm 1 led black
129958	button 12mm 2 led
129986	led 3mm yellow
129984	led 3mm green
129985	led red
129905	digikey , bottom part for all buttons
129962	button 12mm red with led
129957	button 17mm red with led

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**