

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**

Complete Spare Parts List of Martin Mania SCX700

04000302 20uF Capacitor
04401102 2x2x2mm Magnet (Gobo, Gobo Rotate, Color)
04503513 Transformer
04540024 Ballast
05020043 Fuse (3.15AT - Mains In - 20x5mm)
05040038 100° Thermostat
05701206 Motor (Gobo)
05701603 Motor (Color)
05701604 Motor (Pan, Gobo Rotate)
05701625 Motor (Shutter)
05701658 Motor (Tilt)
08072310 Finger-Screw for Main Cover
08112305 Handwheel for Mounting Bracket
16040280 Belt (Color)
18260290 starter
41002093 Reflector
41102061 Heat Filter (Glass Only)
55430045 Mirror w/ Bracket
55430046 Shutter Assembly
55430322 Mounting Bracket
55430333 gobo Guide w/ Bearings
55430335 Color Wheel
55430336 Gobo Wheel
62000119 Hall Sensor (Gobo, Color)
62000124 Main PCB
62000508 Display PCB
62003037 Hall Sensor (Gobo Rotate)
62020080 Power PCB
62222068 Fan w/ Plug
97010111 replacement Lamp - Philips CDM-150 SA/T
97010117 Replacement Lamp - Philips MSD-150/2
11820008 XLR Cable, 3Pin Male to 3Pin Female (16.4 Ft)
11501501 Mains Power Cable (IEC to Edison)
90430084 Mania SCX-700 (EU 220-240V)
90430085 Mania SCX-700 (US 110-120V)

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**