

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Complete Spare Parts List of ARRI EB 6/12

L4.82606.E	HF-gate drive board	HF-Gate-Ansteuerung
L4.82513.E	Mains switch	Netzschalter
L4.82559.E	HF-capacitor board	HF-Kondensator-Platine
L4.82560.E	Start resistor board	Startwiderstand-Platine
L4.82608.E	Input capacitor	Ladeelko
L4.82550.E	HF-snubber board	HF-Entlastung
L4.82552.E	LF-snubber board	NF-Entlastung
L4.82502.E	Rubber foot-set cpl. (4 pieces)	Gummifuß-Set kpl. (4 Stück)
L4.82605.E	Control board	Regelkarte
L4.82548.E	LF-base drive board	NF-Ansteuerung
L4.82532.E	Power FET module	Power FET Modul
L4.82533.E	Diode module	Diodenmodul
L4.82607.E	IGBT-Module	IGBT-Modul
L4.82514.E	Earth test switch	Erdtaster

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria