

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Complete Spare Parts List of Martin Mac250 Wash

04030092 35uF Capacitor
04520011 Transformer
04540010 Ballast
05020020 Fuse (6.3AT - Mains In)
05247204 Fuse Holder (Mains In)
05520503 Micro-switch (Pan)
05701804 Motor (Pan)
11850053 Wireset - High Voltage (Base to Arm)
11860087 Wireset (Base to Arm)
16040050 Belt (Pan)
18400030 Opto-Encoder Wheel (Pan)
62000082 Display PCB
62003008 Opto-Sensor (Pan)
62003013 Thermistor PCB
62004554 XLR PCB (3P In/Out, 5P In/Out)
62005006 Voltage/Frequency Selector PCB
62222013 Fan (Base)
62410005 Base Cover
02121014 6204 Driver Chip
05000001 Lamp Relay
05020009 Fuse (2AT - Main PCB)
05020020 Fuse (6.3AT - Main PCB)
05520503 Micro-switch (Tilt)
05701804 Motor (Tilt)
16040090 Belt (Tilt)
18400030 Opto-Encoder Wheel (Pan)
55225627 Arm Cover w/o Tilt Lock
62000088 Main PCB
62003008 Opto-Sensor (Pan)
62222066 Fan (Yoke)
04401102 Magnet 2x2x2mm
05040018 140° Thermostat
05221213 Lamp Socket
05701202 Motor (Cyan, Magenta, Yellow, Color)
05701602 Motor (Frost)
05701603 Motor (Shutter)
06020005 Starter
11860127 Wireset (Arm to head)
17300080 Plastic Adaptor for Color Filters
20800140 Air Filter
41000060 Reflector

41102071 Heat Filter (Glass Only)
41204022 Front Lens (Glass Only - Fresnel)
55225625 Head Cover w/ 1/4 Turns
62003013 Thermistor PCB
62003017 Hall Sensor (Cyan, Magenta, Yellow, Color)
62003021 Lightsensor PCB
62222049 Fan (Head)
62326055 Yellow Wheel
62326057 Cyan Wheel
62326058 Magenta Wheel
62326059 Color Wheel
62331014 Frost Assembly
62326056 Dimmer Blade (Universal)
34204026 Foam (Bottom Insert)
34204016 Foam (Top Insert and Lid Insert - 2 pcs)
19400060 Castor (Wheel)
08240609 Latch (2 pcs)
08052701 m3 Lock Nut (Holds PCB to Yoke)
08070410 M4x30mm Phillips PH Screw (Lamp Removal)
08070431 M4x25mm Phillips PH Screw (Arm Covers)
08070502 M4x12mm Phillips CS Screw (Base Covers)
08071210 M4x35mm Allen Screw (Lamp Adjustment)
08111214 M6x30mm Allen Screw (Wheels to Case)
08230113 1/4 Turn Retainers (Main Head Cover)
08240101 1/4 Turn Screws (Main Head Cover)
08240106 1/4 Turn Springs (Main Head Cover)
08240109 1/4 Turn Receptacle (Main Head Cover-Rear)
08240127 1/4 Turn Receptacle (Main Head Cover-Front)
97010100 Replacement Lamp - Philips MSD-250/2
41600053 Wide Angle Diffuser Lens
91602008 Omega Bracket
91510014 Flightcase (Dual - Empty)
11501501 Mains Power Cable (IEC to Edison)
11820008 XLR Cable, 3Pin Male to 3Pin Female (16.4 Ft)
90225810 MAC 250 Wash in Cardboard Box (1)
90225800 MAC 250 Wash in Dual Flightcase (2)

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**