

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Complete Spare Parts List of Martin Mac 700 Wash

02121014 6204 Driver Chip
02121015 6205 Driver Chip
02121805 RS485 SMD Transceiver Chip (DMX)
05020020 Fuse, 6.3AT (SMPS)
05020025 Fuse, 10AT (Main @ 208-240VAC)
05020027 Fuse, 15AT (Main @ 100-120VAC)
05031004 Fuse Holder Assembly (Main)
05520503 Microswitch (Pan,Lamp Door)
05701804 Motor (Pan,Tilt)
06100013 Ballast
11860178 Wireset (Base to Yoke - 1/2/3/4/5)
16040050 Belt (Pan)
18400030 Optical Encoder Tooth-Wheel (Pan,Tilt)
55245011 SMPS (Power Supply)
62000093 Display PCB
62000116 Main PCB (When ordering request Wash SW)
62003013 Thermistor (Base)
62003015 Optical Sensor (Pan)
62004624 XLR PCB
62006021 Mains Filter PCB
62222077 Fan (Base)
04401102 Magnet (All Effect Wheels)
05040039 110° Thermosensor
05221209 Lamp Socket
05520503 Microswitch (Pan,Lamp Door)
05701203 Motor (Beam Shaper Rot., CMY Flags)
05701610 Motor (Shutters)
05701611 Motor (Beam Shaper I/O, Zoom, Color)
16040310 Belt (Zoom Short)
16040320 Belt (Zoom Long)
16040470 Belt (Beam Shaper I/O, Beam Shaper Rot.)
16040510 Belt (Color)
16060050 Belt (CMY Flags)
16740020 Snap-Lock for Timing Belt on CMY Flags
17300020 Plastic Adaptor for Color Filters
20800170 Air Filter
41002080 Reflector
41102070 Heat Filter (Glass Only)
41204029 Lensgroup 1 (Front Fresnel Lens)
41203035 Lensgroup 2 (Zoom Lens)

55240003 Cover (Main Head w/ 1/4 Turns)
62002507 Microswitch PCB (CMY Flags)
62003013 Thermistor (Head - Right)
62090166 Hall Sensor PCB (Beam Shaper, Color)
62003029 Temp Sensor (Lamp)
62090165 Microswitch PCB (Beam Shaper I/O, Zoom)
62228024 Starter
62323038 Heat Filter Module (Assembled)
62325093 Shutter Blade (Universal)
62326076 Color Wheel w/ Color Filters
62331042 Magenta Flag Pair
62331043 Cyan Flag Pair
62331044 Yellow Flag Pair
62331045 CTC Flag Pair
62328020 Beam Shaper w/ Bearings
62400506 Fan Assembly (Lamp Section - Pair)
05520506 Microswitch (Tilt)
05701804 Motor (Pan,Tilt)
11860121 Wireset (Yoke to Head - 4/5)
11860181 Wireset (Yoke to Head - 2)
16040090 Belt (Tilt)
18400030 Optical Encoder Tooth-Wheel (Pan,Tilt)
55225627 Cover (Arm)
55225704 Cover (Arm with Tilt Lock)
62003008 Optical Sensor (Tilt Feedback)
08052701 M3 Lock Nut (Holds Main PCB to Plate)
08070502 Screw (Base Covers - Top)
08111214 M6x30mm Allen Screw (Wheels to Case)
08240107 1/4 Turn Retaining Ring (Head Cover)
08240108 1/4 Turn Receptacle (Head Cover Rear)
08240113 1/4 Turn Wingbolt (Omega Bracket)
08240114 1/4 Turn Retainer (Omega Bracket)
08240127 1/4 Turn Receptacle (Head Cover Front)
08240134 1/4 Turn Stud (Head Cover)
08240135 1/4 Turn Spring (Head Cover)
08240609 Butterfly Latch
19400060 Castor (Wheel)
34204023 Foam (Yoke - Side - 1 pc)
34204064 Foam (Lid and Top - Base Support - 2 pcs)
34204066 Foam (Bottom - Front Lens Support - 1 pc)
97010312 Replacement Lamp - MSR-700/SA/2 DE
97010212 replacement Lamp - Osram HTI-700/D4/75
91602001 Omega Bracket
91611263 Frost Filter
91510020 Empty Dual Flightcase
90207400 MAC700 Profile in Cardboard (1) Black
90207401 MAC700 Profile in Dual Flightcase (2) Black

90207430 MAC700 Profile in Cardboard (1) White

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**