

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Complete Spare Parts List of High End Systems Road Hog

80320017	ARM REST
90604008	BATTERY 3V LITHIUM CR2032
A2080002	DESKLIGHT
25091402	DESKLIGHT POWER HARNESS RIGHT SIDE : Includes desk light socket,
90409288EF	DESKLIGHT POWER HARNESS LEFT SIDE: Includes desk light socket,
90409281EF	DESKLIGHT & WORKLIGHT POWER HARNESS ADAPTER (left side only)
80030062	DMX OUTPUT PCB USB to DMX x 4
99263122	DUAL LCD DISPLAY BRACKET
A2040001	DUST COVER
90306086	ENCODER
90410155	ENCODER WHEEL
90405330EF	FADER
25090003	FADER KNOB
90903025	FLASH DRIVE USB 1 GB
90409286EF	FLASH DRIVE HARNESS
90903003EF	HARD DRIVE, IDE
90903003EF	HARD DRIVE, S-ATA
99263118	HARD DRIVE BRACKET
25091508	KEY CAP SET COMPLETE
A2080001	LCD DISPLAY/TOUCHSCREEN
90409282EF	LCD DISPLAY/TOUCHSCREEN POWER HARNESS
99070014EF	POWER SUPPLY
80070441	SIDE BEZEL LEFT
80070440	SIDE BEZEL RIGHT
A2100002	SIDEMARKER LED ASSEMBLY (blue LEDs below armrest)
90409280EF	SIDEMARKER LED POWER HARNESS
90409292EF	SOFT POWER SWITCH ASSEMBLY
90409285EF	SOFT POWER SWITCH HARNESS (from Motherboard to Soft Power Switch)
25091077	TRACKBALL
25091327	TRACKBALL ADAPTER PLATE
25091105	TRACKBALL BUTTON
25091328	TRACKBALL CABLE
90409283EF	USB POWER HARNESS (Motherboard to Front Panel PCB and DMX PCB)
90409279	USB Panel Mount, (Two USB ports on rear of console including cable)
90902051	VIDEO CARD
99260514	VIDEO CARD BRACKET
A2100001	WORKLIGHT LED ASSEMBLY (white LEDs below armrest)

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**