

Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Complete Spare Parts List of Clay Paky A.leda Wash K10

CAB01I/801	Base wiring harness
CAB002/801	Powercon wiring harness
CAB01M/801	Led wiring harness
694003/002	Power supply cord
030361/001	Main switch 6A
ALI001	Power board 48Vdc/400W
SCH00S	CPU and Pan/Tilt electronic board
699176	Pan/Tilt Encoder board(CP0109)
699178	User push button board
DIP001/001	LCDDisplay board
699177	Hall sensor PCB
SCH00U	Driver LED board
SCH00R	Central LED board –A.leda Wash K10 CConly
SCH00P	Central LED board –A.leda Wash K10 TWonly
SCH00Q	Central LED board –A.leda Wash K10 Wonly
SCH005	DMX board (5 pin)
030386	Battery
030257	Female Powercon
021792	Belt HTD 384-3M-9-Pan
021793	Belt HTD 435-3M-9-Tilt
270079/802	Head fan
288079/801	Base Papst 614F fanwires 440mm
288079/802	Base Papst 614F fan wires 180mm
LEP000	Plate lens
LEP001	Conic lens
270015/801	Head cover front
270016/801	Head cover back
270014/801	Plastic yoke cover
270014/802	Plastic yoke cover with lever hole
270013/801	Plastic central yoke cover
092018/001	Back panel frame
270090/801	Metal Base cover
270216/001	Plastic transparent front cover
CAB01I/801	Base wiring harness
CAB002/801	Powercon wiring harness
CAB01M/801	Led wiring harness
694003/002	Power supply cord
270191/801	Zoom assembly motor
031947	Motor, single step 24HC4301-01

**Order your Spare Parts here -> <http://www.lichtboxx.com/index.php/cPath/158/language/en>
www.lightspares.com | ©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria**