

channel	function	type of control	effect	decimal
1	Base (pan) coarse	proportional	coarse control of the base movement	0-255
2	Base (pan) fine	proportional	fine control of the base movement	0-255
3	Yoke (tilt) coarse	proportional	coarse control of the Yoke movement	0-255
4	Yoke (tilt) fine	proportional	fine control of the Yoke movement	0-255
5	movement speed	proportional	from fast to slow	0-255
6	dimmer	step	closed	0-10
		proportional	from close to open	11-255
7	cyan	step	white, no effect	0-10
		proportional	proportional cyan control from white to cyan	11-255
8	magenta	step	white, no effect	0-10
		proportional	proportional magenta control from white to magenta	11-255
9	Yellow	step	white, no effect	0-10
		proportional	proportional yellow control from white to yellow	11-255
10	Lamp right on/off	step	lamp off	0-100
			lamp on	241-255
11	Lamp left on/off/ reset	step	lamp off	0-10
			Park (idle, no function)	10-30
			lamphouse motor reset (only once)	31-99
			motor reset (only once)	100-240
			lamp on	241-255
Back panel can inhibit lamp off function				
note 1: 2 numbers close to the end limit levels cannot be used as unstable levels				
note 2: lamp ON/off/reset functions has a delay time of 6 second to prevent accidental activation.				
note 3 :on/off lamp mode is not affected unless an opposite value is received				
Fixture type: SuperCyc			Chart name: DMX 512	
Chart number: 193		Release: 2	Date: 05/01/2001	

channel	function	type of control	effect	decimal
1	Base (pan) coarse	proportional	coarse control of the base movement	0-255
2	Base (pan) fine	proportional	fine control of the base movement	0-255
3	Yoke (tilt) coarse	proportional	coarse control of the Yoke movement	0-255
4	Yoke (tilt) fine	proportional	fine control of the Yoke movement	0-255
5	movement speed	proportional	from fast to slow	0-255
6	dimmer	step	closed	0-10
		proportional	from close to open	11-255
7	cyan	step	white, no effect	0-10
		proportional	proportional cyan control from white to cyan	11-255
8	magenta	step	white, no effect	0-10
		proportional	proportional magenta control from white to magenta	11-255
9	Yellow	step	white, no effect	0-10
		proportional	proportional yellow control from white to yellow	11-255
10	Lamp right on/off	step	lamp off	0-100
			lamp on	241-255
11	Lamp left on/off, all lamps on/ reset	step	lamp off	0-10
			Park (idle, no function)	11-29
			lamphouse motor reset (only once)	30-100
			motor reset (only once)	101-170
			2 lamps on (override ch 10)	171-249
			lamp on	250-255
Back panel can inhibit lamp off function				
note 1: 2 numbers close to the end limit levels cannot be used as unstable levels				
note 2: lamp ON/off/reset functions has a delay time of 6 second to prevent accidental activation.				
note 3 :on/off lamp mode is not affected unless an opposite value is received				
Fixture type: SuperCyc			Chart name: DMX 512	
Chart number: 193		Release: 3	Date: 05/01/2001	

channel	function	type of control	effect	decimal
1	Base (pan) coarse	proportional	coarse control of the base movement	0-255
2	Base (pan) fine	proportional	fine control of the base movement	0-255
3	Yoke (tilt) coarse	proportional	coarse control of the Yoke movement	0-255
4	Yoke (tilt) fine	proportional	fine control of the Yoke movement	0-255
5	No effect	step	no effects	0-255
6	dimmer	step	closed	0-10
		proportional	from closed to open	11-255
7	cyan	step	white, no effect	0-10
		proportional	proportional cyan control from white to cyan	11-255
8	magenta	step	white, no effect	0-10
		proportional	proportional magenta control from white to magenta	11-255
9	Yellow	step	white, no effect	0-10
		proportional	proportional yellow control from white to yellow	11-255
10	Lamp right on/off	step	lamp off	0-100
			lamp on	241-255
11	Lamp left on/off, all lamps on/ reset	step	lamp off	0-10
			Park (idle, no function)	11-29
			lamp house motor reset (only once)	30-100
			motor reset (only once)	101-170
			2 lamps on (override ch 10)	171-249
			lamp on	250-255
Back panel can inhibit lamp off function				
note 1: 2 numbers close to the end limit levels cannot be used as unstable levels				
note 2: lamp ON/off/reset functions has a delay time of 6 second to prevent accidental activation.				
note 3: on/off lamp mode is not affected unless an opposite value is received				
Fixture type: SuperCyc			Chart name: DMX 512	
Chart number: 193		Release: 4	Date: 10/03/2001	

channel	function	type of control	effect	decimal
1	Base (pan) coarse	proportional	coarse control of the base movement	0-255
2	Base (pan) fine	proportional	fine control of the base movement	0-255
3	Yoke (tilt) coarse	proportional	coarse control of the Yoke movement	0-255
4	Yoke (tilt) fine	proportional	fine control of the Yoke movement	0-255
5	movement speed	proportional	from fast to slow	0-255
6	dimmer	step	closed	0-7
		proportional	from close to open	8-255
7	dimmer speed	proportional	from fast to slow	0-255
8	cyan	proportional	proportional cyan control from white to cyan	0-255
9	magenta	proportional	proportional magenta control from white to magenta	0-255
10	Yellow	proportional	proportional yellow control from white to yellow	0-255
11	colour speed	proportional	from fast to slow	0-100
12	Lamp right on/off	step	lamp off	0-100
			lamp on	241-255
13	Lamp left on/off/ reset	step	lamp off	0-100
			Park (idle, no function)	101-114
			motor reset (only once)	115-140
			lamp on	141-255
Back panel can inhibit lamp off function				
note 1: 2 or 4 numbers close to the end limit levels cannot be used as unstable levels				
note 2: lamp ON/off/reset functions has a delay time of 6 second to prevent accidental activation.				
note 3 :on/off lamp mode is not affected unless an opposite value is received				
Fixture type: SuperCyc			Chart name: DMX 512	
Chart number: 193		Release: 1	Date: 19/09/2000	